

Ergo Touchpad Buttons

1. Right mouse click
tap in the upper right hand
corner



2. Left mouse click
tap anywhere on the surface
or tap the left button



3. Drag-n-drop & highlight:
"Quickly!" tap twice holding
down and dragging your
finger on the second tap.

4. Scroll
by dragging
along the right
side edge



Remember: You never run out of dragging space! If you drag or draw something to the very edge of the touchpad, it automatically senses you are at the edge and gives you 3 seconds to lift up and reposition your finger.

ERGO TOUCHPAD CONTROL CENTER



Our touchpads work automatically when plugged in but if you want Gestures, more speed, control, precision, 8 different scrolling options, rotation, programmable features, motion extenders and much more.....

Free program for PC
FULL VIDEO INFOMERCIAL AND DOWNLOAD AT
WWW.ErgoTouchpad.com

Multi-Finger Gestures: For rotate, zooming, 2 finger panning, and 3 finger flick that can also be programed to open up programs and much more.

Scrolling: 8 different scrolling options including Horizontal, Vertical, Zoom, Back/Forward, Compatible Scroll, Power Scroll, Circular Scroll and Wheel mouse scroll.

Adjust pointer speed and acceleration to make your cursor fly! and also enable or disable motion extenders like glide extend that give you infinite dragging.



Program the right tap zone
to one of 42 functions



TouchGuard gives you added security by Blocking accidental tapping and motion while typing, and Ignore large objects brushing the touchpad does exactly what it says.

Rotate the touchpad 90, 180 or 279 degrees so you can use it sideways or upside down.

Touchpad sounds allow you to hear the different functions engage and can be enabled or disabled.

